

## B1 grid plate 400 mm

- for mounting in a W1 frame

**Material:** sheet metal

**Surface:** powder coated RAL 9003

**Scope of delivery:** 2 x grid sheet half shell, mounting material

**Weight / max. load:** 5,5 kg / 15 kg

**Dimensions (H x W x D):**

398 x 488 x 40 mm, perforation


10 x 10 mm, spacing 38 mm

**Required height:** 400 mm

**Delivery:** single: by parcel service, together with base frame: on pallet

<b>Order no.</b>
------------------

570-410-10
------------



**IMPORTANT NOTE:** when loading modules and accessories, please observe the max. permissible load for the respective base frame or the island.

## B1 grid plate 1500 mm

- for mounting in a W1, W2 or W3 frame\*

**Material:** sheet metal

**Surface:** powder coated RAL 9003

**Scope of delivery:** 2 x grid sheet half shell, mounting material

**Weight / max. load:** 18 kg / 50 kg

**Dimensions (H x W x D):**

1495 x 488 x 40 mm, perforation


10 x 10 mm, spacing 38 mm

**Required height:** 1500 mm

**Delivery:** single: by parcel service, together with base frame: on pallet

<b>Order no.</b>
------------------

570-410-00
------------



**IMPORTANT NOTE:** when loading modules and accessories, please observe the max. permissible load for the respective base frame or the island.

## B1 thread module

- for mounting a B1 grid sheet 1500 mm in a W2 or W3 frame\*

**Material:** sheet metal

**Surface:** powder coated RAL 9003

**Scope of delivery:** threaded strip, adapter plate, mounting material

**Weight:** 2,5 kg

**Dimensions (H x W x D):**

approx. 1600 x 36 x 60 mm

**Required height:** 1500 mm

**Delivery:** single: by parcel service, together with base frame: on pallet

<b>Order no.</b>
------------------

570-000-50
------------



\* The thread module is required 1 x for installation of the B1 grid sheet 1500 mm in a W2 frame. When installing the B1 grid sheet 1500 mm in a W3 frame, it is required 1 x for a lateral installation and 2 x for a central installation.  
 • **IMPORTANT NOTE:** when loading modules and accessories, please observe the max. permissible load for the respective base frame or the island.